

HOP SNOWBLOWER DISCHARGE CONTROLLER SERVICE PARTNUMBERS

Please find below parts diagrams that give you the part #s for the individual service parts for the rotation and deflector control components. These parts will fit all blowers produced in the last 5 years that used the current and subbed assembly numbers shown below.

NOTE: The new directional (Rotator) control cables are shorter and run over the engine which will help prevent any cable icing problems.

DISCHARGE CHUTE ROTATOR CONTROL PART NUMBERS

NOTE: Please order # 428273 if #1 (cable) has an adjuster incorporated in the outer cable housing

NOTE: Rotator drum pulley (Item #4) must measure 2.22" to use the p.n. 420674 cables (item #1.) If drum measures 2.76" (early versions) then use (item #5 p.n. 420337) rotator assembly.

KEY #	PART #	DESCRIPTION
1	420674	CABLE (SERVICE PART)
2	420678	ROTATOR HEAD (SERVICE PART)
3	420677	ROTATOR PIVOT HEAD (SERVICE PART)
4	420675	PULLEY PIVOT (SERVICE PART)
5	420337	LEVER/CABLE ROTATOR ASSY (PRIOR #S WERE 198473, 178659 AND 404974)

DISCHARGE CHUTE DEFLECTOR CONTROL PART NUMBERS

KEY #	PART#	DESCRIPTION
1	420679	DEFLECTOR CONTROL HEAD (SERVICE PART)
2	420672	DEFLECTOR CONTROL CABLE (SERVICE PART)
3	420673	DEFLECTOR CONTROL ASSEMBLY (PRIOR NUMBERS WERE 198475 AND 178674)