

LCT

136 SINGLE STAGE HOP SNOW ENGINE SERVICE KIT 435945, 436021

3	Muffler Assembly-Snow	437989	30	Crankcase Cover Assy	438002
6	Snow Carburetor Assy	437990	31	Black Oil Dipstick	420961
8	Fuel Primer Bulb With Hose	437123	34	Spark Plug Boot	436966
10	Electric Starter Assy	437124	36	Governor Arm Assy	438003
10A	European 230V Electric Starter	437125	37	Governor Shaft	438004
11	Key Switch Assy	424954	38	Governor Gear Assy	429646
12	CDI Box	424955	39	Camshaft	438005
17	Recoil Starter Assembly-Snow	436967	40	Cylinder Head Assy	438006
18	Starter Cup Small	437991	41	Spark Plug	424939
19	Snow Starter Grip	424968	44	Piston And Rod Assy	438007
20	Blower Housing Assembly Electric Start - Snow (Black)	437992	46	Vapor Shield	429260
20A	Blower Housing Assembly Manual Start - Snow (Black)	437993	47	Seal Kit	438008
21	Shield, Cylinder	437994	48	Wire Harness	437967
22	Shield, Flywheel - Electric Start (If Equipped)	437995	49	Crankshaft	438009
22A	Shield, Flywheel - Manual Start	437996	50	Speed Control Bracket	429259
23	Valve Cover	437997	52	Rocker Arm Kit	438010
26	Electric Start Flywheel Assy	437998	53	Push Rod Kit	438011
26A	Manual Start Flywheel Assy	437999	54	Cylinder Assembly	438012
27	High Oil Fill Tube Assy	438000	56	Gasket Kit	438013
28	Flywheel Fan	438001	57	Fuel Hose Kit	438014
29	Ignition Coil Assy	420595	62	Non-Removable Oil Plug	429598
			65	Oil Drain Plug Kit	435495

rev. 08/18/10

