


REPAIR PARTS SNOW THROWER - - MODEL NUMBER PR621 (96182000301)
ENGINE, LCT COMPLETE ENGINE-444168,444169,444170,444171



REPAIR PARTS SNOW THROWER - - MODEL NUMBER PR621 (96182000301)
ENGINE, LCT COMPLETE ENGINE-444168,444169,444170,444171

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
3	444277	MUFFLER ASSEMBLY-SNOW	27	444091	HIGH OIL FILL TUBE ASSY
6	437122	SNOW CARBURETOR ASSY	28	420586	FLYWHEEL FAN
8	437123	FUEL PRIMER BULB WITH HOSE	29A	443934	IGNITION COIL (CDI) (USED ON ENGINES WITHOUT REF. 12
10	437124	ELECTRIC STARTER ASSY	30	420606	CRANKCASE COVER ASSY
10A	437125	EUROPEAN 230V ELECTRIC STARTER	31	420961	BLACK OIL DIPSTICK
11	424954	KEY SWITCH ASSY	34	436966	SPARK PLUG BOOT
17	436967	RECOIL STARTER ASSEMBLY-SNOW	36	420601	GOVERNOR ARM ASSY
18	436968	STARTER CUP SMALL	37	420602	GOVERNOR SHAFT
19	424968	SNOW STARTER GRIP	38	429646	GOVERNOR GEAR ASSY
20	424971	BLOWER HOUSING ASSEMBLY ELECTRIC START - SNOW (BLACK)	39	420584	CAMSHAFT
20A	429230	BLOWER HOUSING ASSEMBLY MANUAL START - SNOW (BLACK)	40	420578	CYLINDER HEAD ASSY
21	437119	SHIELD, CYLINDER	41	424939	SPARK PLUG
22	424975	SHIELD, FLYWHEEL - ELECTRIC START (IF EQUIPPED)	44	420582	PISTON AND ROD ASSY
22A	429596	SHIELD, FLYWHEEL - MANUAL START	46	429260	VAPOR SHIELD
23	420580	VALVE COVER	46A	444275	INTAKE SHIELD
26	429235	ELECTRIC START FLYWHEEL ASSY	47	429599	SEAL KIT
26A	420585	MANUAL START FLYWHEEL ASSY	48	444276	WIRE HARNESS
			49	429600	CRANKSHAFT
			50	429259	SPEED CONTROL BRACKET
			52	429691	ROCKER ARM KIT
			53	420579	PUSH ROD KIT
			54	436567	CYLINDER ASSEMBLY
			56	429601	GASKET KIT
			57	438014	FUEL HOSE KIT
			62	435495	NON-REMOVABLE OIL PLUG
			65	435495	OIL DRAIN PLUG KIT