


ILLUSTRATED PARTS LIST

MODEL NUMBER 961380044
MFG. ID. NUMBER 96138004400

WEED EATER LAWN MOWER - MODEL NUMBER 961380044 (MFG. ID. NUMBER 96138004400)



WEED EATER LAWN MOWER - MODEL NUMBER 961380044 (MFG. ID. NUMBER 96138004400)

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 19 60-25	Control Bar	30	532 40 16-29	Spacer	55	532 85 10-74	Hardened Washer
2	532 44 82-63	Upper Handle	31	532 16 57-60	Discharge Deflector	56	532 40 67-12	21" Blade
3	580 63 86-02	Bar, Lower Handle	32	532 44 15-59	Selector Spring, Rear	57	581 54 79-01	Blade Adapter
4	581 90 21-01	Rope Guide	33	532 08 78-77	Selector Knob	58	532 15 21-24	Hinge Spring
5	581 91 26-01	T-Knob	34	532 41 06-00	Axle Arm Assembly, Rear, LH	59	- - -	Engine, Briggs & Stratton, Model No. 9P602-0085-F1
6	532 19 15-74	Handle Bolt	35	532 42 65-89	Locknut, Hex 5/16-18			(For engine service and replacement parts, call B&S at 1-800-233-3723)
7	532 06 64-26	Wire Tie	36	532 40 16-38	Shoulder Bolt			
8	874 78 05-12	Bolt, Hex Head 5/16-18 x 3/4	37	532 43 05-01	Wheel & Tire Assembly, Front			
9	532 15 41-32	Hinge Bracket	39	532 40 91-49	Flanged Locknut, Hex			
10	532 16 57-54	Mulcher Door	40	532 41 19-49	Frame, Grassbag	61	532 40 91-48	Nut, Hex
11	532 44 09-34	Engine Zone Control Cable	41	532 19 41-86	Hinge Screw	62	873 80 04-00	Locknut, Hex 1/4-20
12	532 17 88-48	Screw, Hex Washer Head #10-16 x 5/8	42	532 40 54-21	Spring, Rear Door, LH	65	532 08 83-48	Washer, Flat
			43	532 40 54-23	Spring, Rear Door, RH	66	532 19 74-80	O-Ring
13	532 43 00-34	Up-Stop Bracket	44	532 18 41-93	Bolt, Rear Door	73	532 40 16-30	Washer, Curved, Cylindrical
14	532 19 19-38	Handle Knob	45	532 15 04-06	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1	74	532 12 50-78	Washer, Special, Engine
15	532 05 17-93	Hairpin Cotter				76	532 41 05-89	Baffle, Rear
18	817 60 04-06	Screw 1/4-20 x 3/8	46	532 40 47-63	Danger Decal	77	817 41 13-12	Screw, Rear Baffle
19	532 40 66-89	Axle Arm Assembly, Front, LH	47	532 75 11-53	Nut, Hex	83	532 42 85-01	Baffle, Front
20	532 40 66-90	Axle Arm Assembly, Front, RH	48	532 41 06-01	Axle Arm Assembly, Rear, RH	84	817 00 05-10	Screw, Front Baffle
21	532 41 68-60	Kit, Rear Skirt	49	581 01 03-22	Wheel & Tire Assembly, Rear	87	532 43 75-16	Plug, Handle Bar
22	532 40 64-28	Selector Spring, Front	50	581 00 21-06	Grassbag	88	586 21 25-01	Bolt, Carriage
23	532 41 06-03	Rear Door Assembly	51	532 14 72-86	Hinge Rod	89	873 97 05-00	Nut, Hex
25	580 91 56-02	Handle Bracket Assembly, LH	52	532 44 20-11	Kit, Lawn Mower Housing (Includes Key Number 46)	- -	532 40 47-64	Warning Decal (not shown)
26	580 91 57-02	Handle Bracket Assembly, RH				- -	115 58 77-27	Operator's Manual, English
28	532 41 44-41	Wheel Adjusting Bracket, LH	53	532 85 10-84	Screw, Hex Head, Grade 8	- -	115 58 77-46	Operator's Manual, Spanish
29	532 41 44-40	Wheel Adjusting Bracket, RH				- -	115 58 77-31	Operator's Manual, French
			54	532 85 02-63	Helical Lockwasher			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.