

ROTARY LAWN MOWER - - MODEL NUMBER PR65N22SHA

KEY NO.	PART NO.	DESCRIPTION
1	132004	Locknut 1/4-20
2	170285	Control Bar
3	179585	Rope Guide
4	172139X479	Upper Handle
5	169708X479	Lower Handle
6	63601	Locknut 1/4-20
7	131959	Handle Bolt 5/16-18
8	144929	Hex Washer Head Screw 1/4-20 x 2-1/8
9	170297	Throttle Control
11	133107	Engine Zone Control Cable
12	750634	Hex Washer Head Screw #10-24 x 1/2
13	850733X004	Up-Stop Bracket
14	111190X	Cable Clamp
15	83816	Screw #10 x 5/8
16	170146	Handle Knob
19	51793	Hairpin Cotter
21	165858	Rear Deflector
22	66426	Wire Tie
23	160831	Discharge Guard
27	160832	Torsion Spring
30	160833	Hinge Rod
33	63124	Locknut 5/16-18
34	170373X479	Wheel Bracket Support (Left)
35	170374X479	Wheel Bracket Support (Right)
36	160835X007	Wheel Bracket Adjuster
39	168360X004	Selector Spring
40	170143	Selector Knob
41	180410X004	Axle Arm Assembly (RR)
43	183901	Spacer
44	160828	Shoulder Bolt

KEY NO.	PART NO.	DESCRIPTION
45	180203	Wheel Assembly (Rear)
46	83923	Locknut 1/16-18
47	143593	Wheel Assembly (Front)
48	57143	Washer
50	180660	Hubcap
51	74760514	Hex Head Bolt 5/16-18x
52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
55	107339X	Danger Decal
59	165187	Lawn Mower Housing (Incl. Key Nos. 55)
61	851514	Blade Adapter
62	141114	22" Blade
63	851074	Hardened Washer
64	850263	Helical Lockwasher 3/8
65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
67	---	Engine, Briggs & Stratton, Model No. 123K02 (Order parts from engine manufacturer)
70	180409X004	Axle Arm Assembly (LR)
72	167132X004	Axle Arm Assembly (LF)
73	167133X004	Axle Arm Assembly (RF)
74	166785	Nut
75	160830	Plate. Mulcher
76	161622	Clip. Closeout
77	74760412	Screw
80	180624	Hubcap
--	172782	Operator's Manual (English)
--	172783	Operator's Manual (French)
--	162300	Warning Decal(Not Shown)
--	186172	Replacement Parts Manua

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm