


Ref #	Part Number	Qty	Description
1			Engine, Craftsman, Model Number LEV115
2	150406		Bolt, Engine Mounting 3/8-16
3	179466		Pulley, Engine
5	181701		Cover, Engine, with Screen
6	174274		Knob, Engine Cover
7	174030		Stud, Engine Cover
8	169821X479		Handle, Lower
9	150078		Screw, Hex Washer Head 5/16-18 x .75
10	169797X479		Handle, Upper
11	131959		Bolt, Handle
12	136376		Knob, Handle
16	179585		Guide, Rope
18	66426		Wire Tire
19	176983		Control Bar
20	174934		Throttle Control
21	158755		Screw, Hex Washer Head
22	169787		Axle Shaft Assembly
23	150078		Screw, Hex Washer Head 5/16-18 x .75
24	174751		Washer, Axle
26	174721		Wheel, 10 x 1.75
27	83923		Hex Flange Locknut 3/8-16
28	161699		Drive Control
29	174034		Decal, Warning
30	174723		Decal, Engine Cover
31	172221X479		Bracket, Axle Support
33	132004		Nut
34	86899X004		Bracket, Upstop
35	750634		Screw, Thd. Roll. #10-24 x 1/2
36	851084		Bolt, Hex Head
37	850263		Washer, Lock
38	851074		Washer, Flat, Hardened
39	57143		Washer, Wave
	177817		Operator's Manual
	182808		Repair Parts Manual



Ref #	Part Number	Qty	Description
1	174024X550		Chassis Assembly
2	174040		Line, Trimmer .155 diameter x 18.75 long
3	150078		Screw, Self-Tapping 5/16-18 x 1
4	169790		V-Belt
5	172145X004		Bracket, Idler
6	166042		Pulley, Idler, V-Groove
7	173716		Bolt, Hex Head 3/8-16 x 1.25
8	751592		Locknut, Hex 3/8-16
9	166043		Pulley, Idler, Flat
10	160829		Bolt, Shoulder
11	155552		Locknut 5/16-18
12	173717		Spacer
13	174719		Bolt, Shoulder
14	145212		Locknut, Flange
15	173811		Spring, Return
16	180268		Deflector, Bottom
17	57808		Screw 1/4-20 x 1/2
18	178848		Screw #10
20	169764		Cover, Chassis, Top
21	149746		Screw #10-24 x 1-3/4
22	STD541137		Nut, Hex 3/8-24 UNF
23	STD551137		Washer, Lock 3/8
24	STD551037		Washer, Flat 3/8
25	180340		Pulley, Driven
26	172551		Spacer, Pulley
27	174549		Bearing
28	172520		Jackshaft
29	169766X479		Cover, Chassis, Bottom
30	174543		Spindle Housing Assembly (Includes Upper Bearing, Key Number 27)
31	174581		Ring, Retaining, External, 17mm
32	176973		Spring, Locking Plate
33	172519		Locking Plate
34	180338		Carrier Plate Assembly
35	182217		Mow Ball Assembly (Includes Key Numbers 27, 37 and 38)
36	172516		Cover, Bearing
37	174580		Ring, Retaining, Internal, 40mm
38	172523		Mow Ball
39	180334		Bolt, Mow Ball
40	173619		Spindle Assembly, Complete (Includes Key Numbers 22-28 and 30-39)
41	174029		Spacer
45	174596X479		Belt Keeper, Bottom
46	17060408		Screw, Self-Tapping
47	174036		Decal, Instruction
51	179875		Deflector, Rear
52	178848		Screw #10