



# REPAIR PARTS

**Briggs Engine MODEL 021132-0599E1**  
**Note:**  
 Cylinder and Internal Components are **NOT SERVICEABLE**.  
 Use Replacement Engine




SEARS TRIMMER MODEL 358.796160

## ENGINE PARTS



### WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.





Ref.	Part No.	Description	Ref.	Part No.	Description	Part No.	Description
1.	---	Briggs Engine Model 021132-0599E1	18.	699874	Assembly-Wire	Not Shown	
2.	696876	Spark Plug	19.	699944	Grip-Starter Rope(Incl. Rope)		
3.	696891	Screw-Cyl. Head	20.	698031	Screw-Blower Hsg.		
4.	696848	Head-Cylinder	21.	791499	Assy-Pulley/Spring	275064	Manual-Owner's(B&S)
5.	696865	Gasket-Cyl. Head	22.	696928	Nut-Flywheel	275072	Manual-Repair(B&S)
6.	697040	Screw-Muffler Defl.	23.	696879	Seal-Oil	699969	Cup-Oil Fill(B&S)
7.	697039	Deflector-Muffler (Incl. #6)	24.	696930	Dipstick (Incl. o-ring)	19538	Puller-Flywheel(B&S)
8.	697038	Arrestor-Spark	25.	696895	Screw (Starter Clutch)		
9.	697035	Gasket-Exhaust	26.	699888	Cover-Clutch		
10.	696874	Assy-Muffler (Incl. # 6,7,8,9)	27.	699871	Clutch-Starter		
11.	696931	Gasket-Breather	28.	697010	Kit-Engine Gasket Set		
12.	696849	Cover-Valve	29.	698031	Screw-Cam Gear Cover		
13.	696889	Screw-Valve Cover	30.	696871	Tube-Breather		
14.	696885	Assy-Flywheel	31.	696967	Cover-Cam Gear		
15.	696877	Armature-Magneto	32.	696929	Gasket-Cam Gear Cover		
16.	696891	Screw-Magneto	33.	696866	Gasket-Crankcase		
17.	698050	Blower Hsg./Rewind (Incl. 19,21)	34.	696950	Cover-Crankcase(Incl. 33)		
			35.	696889	Screw-Crankcase Cover		
			36.	696936	Shield-Cylinder		
			37.	696889	Screw-Cyl. Shield		
			38.	696895	Screw-Cyl. Shield(A)		

# REPAIR PARTS

SEARS TRIMMER MODEL 358.796160

ENGINE PARTS 



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	790567	Cleaner-Air	13.	696919	Assy-Fuel Tank (Incl. 11,12,14,15)
2.	696923	Filter-Air Cleaner Foam	14.	696921	Cap-Fuel Tank
3.	696868	Gasket-Intake	15.	699876	Sleeve-Fuel Line
4.	696894	Screw-Carburetor			
5.	696867	Gasket-Intake			
6.	696870	Spacer-Carburetor			
7.	696893	Screw-Carburetor Adapter			
8.	696949	Carburetor			
9.	699942	Seal O-ring (Carburetor)			
10.	690800	Nut-Carburetor			
11.	696922	Gasket-Fuel Tank			
12.	696872	Insulator			