


Ref #	Part Number	Qty	Description
1	167163		Handle, Upper Dlx Comf. (Including grip)
2	161105X479		Handle, Lower
3	164265		Grip, Hdl Foam Smooth
4	179585		Guide, Rope, Side
5	132004		Nut, Hex Lockwasher 1/4-20
6	66426		Wire, Tie
7	131959		Bolt, Handle 5/16-18 x 1.75
8	170176		Knob, Handle
9	176281		Bail, Cont. Wire Dlx Comf. Yel
10	161551		Bolt, Sq. Neck
11	73990500		Nut, Hex Lockwasher Ins. 5/16-18 UNC
12	51793		Cotter, Hairpin
13	133107		Engine zonecontrol cable
14	850733X004		Bracket, Upstop
15	83816		Screw, Hex Washer Head Tapping 10-2
16	162085		Kit, Door Rear
17	179885		Seal, Door
18	165261		Plug, Mulcher
19	172306		Kit, Housing
20	161568X479		Handle, Bracket Asm. Left
21	168227X479		Handle, Bracket Asm. Right
22	150078		Screw, Hex Wshd
23	163183		Bolt, Hex Head 5/16-18 x 5/8
24	63124		Nut, Hex Lock Wshr 5/16-18
25	161333		Baffle, Side
26	163409		Screw 12 x 5/8
27	161550		Skirt
28	88652		Screw, Hinge 1/4-20 x 1.25
29	166036X479		Belt Cover, Top
30	851514		Adapter, Blade w/key Longer
31	175064		Blade, 21"
32	851074		Washer, Hardened
33	850263		Lockwasher, Helical Spring 3/8
34	851084		Screw, Hex Head 3/8-24 x 1.38
35	169809		Pulley, Fixed
36	179219		Bearing Support Assy.
37	150406		Bolt, Engine
38			Engine, B&S, Model Number 121602 (Order parts from engine manufacturer)
39	182116		Grass Catcher Bag
40	180026		Grass Catcher Frame
41	107339X		Danger Decal
45	166034		Engagement Rod
46	166041		Bushing
48	169605		Retainer Clip
49	175787X008		Clamp
50	54583		Screw
51	169980		Spacer
52	170868		Wave Washer
53	173041		Belt Cover, Bottom
54	750097		Screw
55	166383X479		Cable Support Bracket
56	63601		Nut

Ref #	Part Number	Qty	Description
57	166391X004		Bracket Assy.
58	57808		Screw
59	166042		V-Groove Pulley
60	166050		Idler Arm Spacer
61	145212		Flange Nut
62	155552		Locknut
63	166022X008		Idler Arm
64	166043		Idler Pulley
65	160829		Shoulder Bolt
66	171962		Door Assy.
67	169699		Deflector, Door
68	88349		Nut
69	170297		Throttle Control
70	144929		Screw
71	54583		Screw
73	87677		Hi Pro Key
74	83816		Screw
75	111190X		Cable Clamp
	162300		Warning Decal (Not Shown)
	172787		Operator's Manual (English)
	172788		Operator's Manual (French)
	181891		Replacement Parts Manual



Ref #	Part Number	Qty	Description
1	173813		Speed Control
2	176280		Bail Control Drive
3	17060408		Screw
4	179049		Drive Cable
5	161537		Cover Drive
6	750634		Screw Thdrol 10-25 x .50
7	166060		V-Belt
8	132010		Nut Lock Flanged 3/8-16 Zinc
9	166049		Pulley Driven
10	166021X004		Belt Keeper Bracket
11	17541011		Screw Hex Wash Head 10-24 X .668
12	166189		Pivot Rod Cover
13	166388		Transmission Asm.
14	145354		Pin Spring Thrust
15	57079		Washer Hardened
16	161584		Rod Connecting
17	161602		Spring Extension
18	160477X004		Spring Selector
19	170203		Knob Selector Spring
20	12000022		E-Ring 7/8
21	163365		Bearing Support
22	169911		Bearing Ball
23	161118X004		Retainer Drive Asm. Stmp.
24	57808		Screw Hex Head Tapping 1/4-20 x .75
25	170011		Drive Pawl
26	166450		Pinion, Drive
27	52160		Washer
28	12000058		E-Ring 7/16
29	180504		Cover, Dust Wheel
30	67725		Washer 1/2 x 1-1/2 x .134
31	57143		Wave Washer
32	180763		Wheel 9 x 2
33	145212		Nut Hex Flange Lock
34	180660		Hubcap
35	160785X004		Shaft Asm. Rear
36	160786X004		Shaft Asm. Front
37	161463		Retainer Front Shaft
38	163409		Screw 12 x 5/8
39	700279		Clip Retainer
40	172323		Wheel 8 x 2
42	83923		Nut, Hex Flange Lock 3/8-16
43	19572216		Washer
44	144929		Screw 1/4 x 2.12
45	751152		Locknut