


REPAIR PARTS

SEARS MODEL 944.414460



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015957	Screw	24.	530056936	Assy-Chassis	48.	530015891	Spring-Recoil
2.	530036491	Cover-Handle	25.	530069572	Kit-Switch	49.	530056939	Housing-Fan
3.	530036097	Trigger-Throttle	26.	530029833	Worm-Oil Pump	50.	530015892	Screw
4.	530036098	Lockout-Throttle	27.	530014410	Assy.-Oil Pump	51.	530015814	Screw
5.	530053443	Lever-Choke	28.	530015896	Screw	52.	530015158	Washer
6.	530015937	Screw	29.	530069342	Kit-Clutch Drum	53.	530038327	Handle-Front
7.	530038985	Spring-Isolator	30.	530015611	Washer-Clutch	54.	530036113	Front Strap-AV
8.	530036130	Handle-Rear	31.	530014949	Assy-Clutch	55.	530015775	Screw-Plate
9.	530015906	Screw	32.	530032119	Bearing-Clutch	56.	530036101	Plate-Isolator
10.	530038986	Spring-Isolator	33.	530015907	Washer-Thrust	57.	530038985	Spring-Isolator
11.	530038471	Assy-Throttle Cable (Incl. Grommet)	34.	530019174	Seal-Oil	58.	530015984	Screw
12.	530069232	Kit-Rope	35.	545047801	Pickup-Oil	59.	530047855	Bar Plate
13.	530037485	Handle-Starter	36.	530056533	Filter-Oil	60.	71-3634	Chain 18"
14.	530016080	Screw	37.	530016037	Screw	61.	71-36372	Bar 18"
15.	530047667	Plate-Baffle Fan	38.	530015814	Screw	62.	530069611	Kit-Bar Adjust (incl. 63,64)
16.	530016071	Nut-Flywheel	39.	530029850	Chain Catcher	63.	530038593	Retainer
17.	530015127	Washer-Flywheel	40.	530015877	Bar Bolt	64.	530015826	Pin-Bar Adjust
18.	530039147	Assy-Flywheel	41.	530016439	Screw	65.	530059645	Assy-ChainBrake
19.	530036043	Plate-Support (Bar Stud)	42.	530014381	Kit-Spike Assy. (Incl. #41)	66.	530015917	Nut-Bar Mounting
20.	530029868	Plug-Vent	43.	530010846	Assy-Oil Cap			
21.	530026119	Valve-Check	44.	530055406	Shield-Heat			
22.	530015922	Nut-Speed	45.	530055322	Clip-"U"			
23.	530010845	Assy-Fuel Cap	46.	530015920	Screw			
			47.	530069313	Kit-Starter Pulley			

B